



FRAME BAG INSTRUCTIONS

At Salsa, we believe that a sense of adventure makes life better. The bicycle can be so much more than just a bike; it's a path to new places, new people, and amazing experiences.

Thank you for your purchase. We hope it makes a good riding experience even better!

Salsa. Adventure by bike.

Congratulations! You've entered the brave new world of frame bag users!

Intended Use

The maximum load weight for the Salsa frame bag is 15 lb (6.8kg).

When loading your frame bag, consider the following:

- Locating heavier items deeper in your frame bag can benefit ride quality by lowering the center of gravity
- Frame bags offer extremely quick access so you may want to keep frequently accessed items near the top and front of your frame bag. There is no wrong way to do this...so use your frame bag as you see fit

▲ WARNING: This product is not designed to carry live cargo.

▲ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to www.salsacycles.com/safety

Frame Bag Installation

1. Remove waterbottle cages from bicycle frame.

NOTE: You may wish to tape over the waterbottle boss holes or put the waterbottle bolts back into the holes to prevent water from entering your frame.

NOTE: Taping over the waterbottle boss holes will create less wear on your frame bag.
2. Hold frame bag in place to get a rough idea of where the Velcro closures will sit when frame bag is mounted to frame.
3. Attach frame bag to toptube using Velcro closures.

NOTE: Don't worry about mounting it perfectly on your first attempt. You will repeatedly fine-tune the closures to position the bag.
4. Attach the frame bag to the downtube using Velcro closures.
5. Look at how the bag is hanging inside the triangle, and determine where the frame bag has play, or needs play, and adjust toptube and downtube Velcro closures accordingly.
6. When satisfied with the position of the toptube and downtube Velcro closures, secure the seat tube Velcro closures.

NOTE: Be sure that the seat tube Velcro closures do not interfere with any front derailleur cable routing or cable actuation.
7. Check the zipper action on the framebag. The frame bag should not be stretched so tightly that closing the zipper is difficult.
8. Before riding the bicycle, check that the frame bag installation is not interfering with your brake cable, brake housing, or brake actuation.

Ongoing Maintenance

To clean the bag, hose down, hand wash, use a mild diluted soap if needed, air dry; DO NOT machine wash or dry as this will possibly delaminate the fabrics. For the zippers, keep them clean. Wash with water after dirty/muddy rides. Clean inner teeth with a tooth brush after big trips. Zippers with a lot of use can be given a bit of TLC by rubbing a candle along the teeth to lubricate slightly.





FRAME BAG INSTRUCTIONS

Warranty

Salsa Cycles warrants this new Salsa product against defects in materials and workmanship for three (3) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of Salsa Cycles, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the Salsa product and is not transferable. In no event shall Salsa Cycles be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

SALSA CYCLES

6400 West 105th Street, Bloomington, MN 55438

Tel: 877-MOTO-ACE Fax: 952-983-6210

www.salsacycles.com

1056 04/13

For additional product and safety information go to salsacycles.com/safety