

TIMBERJACK KIDS FRAMEPACK INSTRUCTIONS

At Salsa, we believe that a sense of adventure makes life better. The bicycle can be so much more than just a bike; it's a path to new places, new people, and amazing experiences.

Thank you for your purchase. We hope it makes a good riding experience even better!

Salsa. Adventure by bike®.

NOTE TO PARENTS OR GUARDIANS

These instructions contain important safety and service information. Adults should make sure children or others who may not understand these instructions are instructed on correct operation, warnings, and bicycle safety before their first ride.

⚠ WARNING: Make sure the frame bags load is evenly balanced and secure before every ride (i.e. no loose straps to get caught in the wheels) This bicycle may behave differently when loaded.

⚠ WARNING: Cycling can be dangerous. Bicycle products should be installed and serviced by a professional mechanic. Never modify your bicycle or accessories. Read and follow all product instructions and warnings including information on the manufacturer's website. Inspect your bicycle before every ride. Always wear a helmet.

Intended Use

The Timberjack Kids Framepack carries gear and clothing within your frame's front triangle, keeping weight centered and out of the way of off-road obstacles.



Intended for ASTM 2 conditions. This is a set of conditions for the operation of a bicycle that includes Condition 1 as well as unpaved and gravel roads and trails with moderate grades. In this set of conditions, contact with irregular terrain and loss of tire contact with the ground may occur. Drops are intended to be limited to 15cm (6") or less.

Compatibility

Each size of the Timberjack Kids Framepack is designed for optimal fit with the corresponding frame size. See salsacycles.com/safety for bag and frame compatibility.

Installation Instructions

NOTE: Installation by an adult is required.

1. Remove water bottle cages from your frame. If you are leaving water bottle cage bolts in the frame, use button head bolts to minimize interference with, and potential damage to, the underside of the Timberjack Kids Framepack. Small pieces of electrical tape over the bolt holes also work well to prevent any potential damage.
2. Detach the hook-and-loop attachment straps, and place the framepack inside the main triangle of the frame.



NOTE: The attachment straps can cause wear to the paint of your frame. To prevent damage, we recommend applying clear packing tape on the frame where the straps come in contact with it. Damage to the bicycle frame from the framepack or protective method is not covered by Salsa Cycles warranty. Keep the frame clean and remove road grit to help prevent wear.

3. Join the hook and loop straps at the toptube first.
 4. Work in a clockwise direction, and join the remaining straps.
 5. Make necessary adjustments for optimal fit.
- ⚠ WARNING:** Dangling straps risk getting caught in the wheel. Be sure to secure all straps before riding. Make sure that the bag and straps do not interfere with the function of your bicycle **BEFORE** attempting to ride. Ensure cargo is distributed evenly.

Ongoing Maintenance

Hand wash with warm water and all-purpose detergent. Air dry.

Warranty

Proof of purchase is required before a warranty claim is processed. Salsa Cycles therefore strongly encourages warranty registration at salsacycles.com. Failure to register will not affect consumer rights under the limited warranty stated above, so long as the consumer can show in a reasonable manner proof of original ownership and the date the Salsa Cycles product was purchased.

If you have any questions contact warranty@salsacycles.com or visit salsacycles.com/support for more warranty information.

SALSA CYCLES

6400 West 105th Street, Bloomington, MN 55438

Tel: 877-668-6223 Fax: 952-983-6210

www.salsacycles.com